


10 Models BV1 & BV2 Ball Valve Assembly Part Numbers



WORKING PRESSURE	1"		2"		2-1/2"		3"		4"		6"		8"		10"	
	Size x Bore	Model BV1 Base No.	Size x Bore	Model BV1 Base No.	Size x Bore	Model BV1 Base No.	Size x Bore	Model BV1 Base No.	Size x Bore	Model BV1 Base No.	Size x Bore	Model BV1 Base No.	Size x Bore	Model BV1 Base No.	Size x Bore	Model BV1 Base No.
3600 PSI	Size x Bore	1" x 13/16"	2" x 1-1/2"	2-1/2" x 1-13/16"	3" x 2-1/16"	3" x 2-9/16"	4" x 3-1/4"	4" x 3-3/4"	-	-	6" x 5-3/16"	8" x 7-1/16"	10" x 9-1/16"			
	Model BV1 Base No.	115-	116-	117-	119-	122-	-	-	-	-	-	-	-	-	-	-
	Model BV2 Base No.	-	-	-	219-	222-	223-	225-	-	-	226-	250-	252-			
5000 PSI	Size x Bore	1" x 13/16"	2" x 1-1/2"	2-1/2" x 1-13/16"	3" x 2-1/16"	3" x 2-9/16"	4" x 3-1/4"	-	6" x 4-1/8"	6" x 4-3/4"	6" x 5-3/16"	8" x 7-1/16"	10" x 8-1/16"			
	Model BV1 Base No.	115-	116-	118-	120-	122-	-	-	-	-	-	-	-	-	-	-
	Model BV2 Base No.	-	-	-	220-	222-	224-	-	227-	228-	236-	250-	254-			
6000 PSI	Size x Bore	1" x 13/16"	2" x 1-1/2"	2-1/2" x 1-13/16"	3" x 2-1/4"	-	4" x 3-1/4"	-	6" x 4-1/8"	6" x 4-3/4"	-	8" x 6-13/16"	10" x 8-1/16"			
	Model BV1 Base No.	115-	116-	118-	121-	-	-	-	-	-	-	-	-	-	-	-
	Model BV2 Base No.	-	-	-	221-	-	224-	-	227-	228-	-	256-	258-			
10,000 PSI	Size x Bore	1" x 13/16"	2" x 1-1/2"	2-1/2" x 1-13/16"	3" x 2-1/8"	3" x 2-5/8"	4" x 3-1/8"	-	6" x 4-1/8"	-	-	8" x 6-1/16"	10" x 8"			
	Model BV1 Base No.	129-	130-	-	-	-	-	-	-	-	-	-	-	-	-	-
	Model BV2 Base No.	-	-	231-	232-	233-	234-	-	235-	-	-	260-	262-			
15,000 PSI	Size x Bore	1" x 5/8"	C O N S U L T F A C T O R Y													
	Model BV1 Base No.	137-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
	Model BV2 Base No.	-	238-	239-	240-	-	242-	-	-	244-	-	246-	-			